

Mobile Access Action Wizard

This tutorial provides you the information needed to setup a mobile access action via the notification wizards.

To get to the starting point of this tutorial:

- Log in as administrator
- Click the “Notifications” tab

1. Adding a notification

a) First click on the “notification wizard”

The screenshot shows the web interface for adding a notification. The top navigation bar includes tabs for Summary, Map, Picture Log, Sensors, Notification (selected), Settings, Applications, and Help. The 'Notification' tab is circled in red with the text "Click notification tab".


The left sidebar contains a "Notification Menu" with the following items: [Begin Notification Wizard](#) (circled in red with the text "Click here to begin setting up a notification"), [Sensor Action Link](#), [Options](#), [View Notification Log](#), [Notification Analyzer](#), and [Help](#).

The main content area displays a table of actions:


Action Type	Action Name
SNMP Trap	SNMP Trap 1
SNMP Trap	SNMP Trap 2
SNMP Trap	SNMP Trap 3
SNMP Trap	SNMP Trap 4
SNMP Trap	SNMP Trap 5
SNMP Trap	SNMP Trap 6
Email	Email 1
Email	Email 2
Email	Email 3
Alarm Sound	Alarm Sound 1
Alarm Sound	Alarm Sound 2
Speech	Speech 1
Speech	Speech 2
Speech	Speech 3
Picture Log	Picture Log 1

Below the table are buttons for "Create", "Duplicate", "Edit", "Remove", and "Test Action".

b) You will now have the notification wizard page displayed, like below.



c) Select mobile access from the notification type options.




Please choose a name for your **Mobile Access** Action. Descriptive Action names increase the simplicity of the system.

This is a preview of the message that will be visible on your mobile. The message visible will include the details relevant to your sensor.

Click **Customize** to change the format of this message. The items in your message with a dollar sign and parentheses e.g. \$[TIME] represents the data to be imported into your message at the time of sending. Please click the Macro Description button for a full list.

The Mobile Log Number is the maximum number of notification messages that will be stored on the securityHawk. These messages will be read only when a mobile phone connects to the system, via Bluetooth, data call or GPRS. A new message will be stored in the Log after each event.



Define the number of re-notification attempts and the interval between each.

Click **Finish** to Save your Action